



Quick Start Guide

1. Install the Bolt in desired location



2. Connect FCTs and voltage leads to BOLT



3. Bolt will indicate hookup status through 3 onboard LEDs



This information and more can be found at:
info.powermonitors.com/bolt-getting-started

LED Indicators After Installation

GREEN, BLUE, YELLOW, OR ORANGE:

Installation is complete



During 2-Minute Countdown

GREEN: Recorder has initialized correctly



PURPLE: CTs are inverted or on incorrect phase



ORANGE: Measurements don't match init. parameters



Quick Start Guide



Install PMI View from the App Store and enable Bluetooth (BLE) on your iOS or Windows device.

Start PMI View and let it discover all the Bolts in the area.

Select a Bolt, then update to the latest firmware if prompted.

Download the recorded data into PMI View, then upload it to PQ Canvass to share with your team.

PMI Software:

PMI View - iOS



PMI View - Windows

PQ Canvass

